


frida baby®

Electric Nail Buffer



Product Name:

Electric Nail Buffer

Model Number:

100001305

09600900

Battery Specs:

2x AAA Batteries

Dimensions:


Device: 35x35x148mm

Case: 175x84x46mm

NAIL YOUR BABY'S MANI-PEDI

Giving your mini a mani is about to get a major makeover. The Electric Nail Buffer smooths edges while keeping baby's cuticles and skin safe, even as they sleep. Switch up the grit with interchangeable heads to tackle tiny talons or coarser kid claws.

Specifications + Features:



- 1 Buffer Pads
- 2 Task Light (1 Brightness Level)
- 3 Directional Button (Right)
- 4 Directional Button (Left)
- 5 LED Lights
 - o Level 3 (High Speed)
 - o Level 2 (Medium Speed)
 - o Level 1 (Low Speed)
- 6 Battery Housing
(Located on the lower back of the ENB body)

**Ergonomic Design:**

Slim pencil grip form factor allows for more control during buffing.

**Task Light:**

Always-on task light that aids precision while buffing, especially in lower light.

**4 Changeable Pads:**

Buffer pads with varying grit levels can be used for little ones from newborns to toddlers.


**Adjustable Power:**

With 3 speeds, you're in full control of how you file and buff.

**Quiet Operation:**

Buff even while baby sleeps with a whisper-quiet motor.

Operating Instructions:

**To turn on/off:**

Press and hold either button for 2 seconds.



Buff **left to right** on baby's nail.



Buff **right to left** on baby's nail.

To select speed:

Press directional button again to cycle between speed settings 1 through 3.

Q: Why are there two direction options?

A: Decide whether you prefer to move left to right or right to left along the baby's nail, then match the buffer pad rotation to that direction for the smoothest experience.




Pro tip - for optimal control and precision, tilt the buffer pointing down to the finger nail.

Assembly Instructions:


Step 1:

Slide off the battery cover in the direction of the arrow.




Step 2:

Place batteries inside the buffer.




Step 3:

Once the batteries are in place and correctly positioned, slide the battery cover back until it is fully closed.



Step 4:

Place the buffer pad over the top of the attachment mount and push down firmly.



WARNING: Choking Hazard – Children can choke and suffocate on the buffer pad. Do not let children play or handle the Nail Buffer or buffer pad.

Choosing a Buffer Pad:

Color:	Grit:	Age:
Orange	Ultra fine	0-3 months
Yellow	Fine	3-6 months
Green	Medium	6-12 months
Blue	Ultra gritty	12 + months

Care & Cleaning:

Cleaning:

- To clean your buffer, wipe gently using a dry or slightly damp cloth.
- Do not use any abrasive cleaners, or solvents on any part of your Electric Nail Buffer.
- Do not submerge or rinse under water.

Storage:

- Avoid direct sunlight.
- Store in a cool, dry place.

Care:

- As your buffer pads wear down from use, they will need to be replaced.
- All replacement parts are available through Frida customer service.

Troubleshooting Guide:

Problem:	Solution:
Product is not turning on	Replace batteries.
Turn off task light	The task light is meant to remain on during usage. Task light will turn off once product is shut off.
Lost head attachment	You can request replacement parts through Frida customer service.

IT'S OFFICIAL: YOU'RE A SMOOTH OPERATOR.

You just finished reading the manual.

Electric Nail Buffer Questions?

frida.com/help

Country of Origin - Made in China

FRIDABABY, FRIDA and all trademarks mentioned herein are the registered and unregistered trademarks of Fridababy, LLC © Fridababy, LLC 2023

Manufactured for (UK, EU Producer):

Fridababy LLC
82 NE 26th Street
Miami, Florida, 33137 USA
fridababy.com

UK Importer:

MedEnvoy UK Limited
85, Great Portland Street,
First Floor
London, W1W 7LT
United Kingdom

EU Importer:

Nasalprodukter Sverige AB
S:t Johannesgatan 2
211 46 Malmö
Sweden

Australia Distributor:

The Amazing Baby Company
11 Maurice Court
Nunawading, VIC 3131
info@tabc.com.au